

DISCLAIMER: This document was produced to support MSF staff taking into account MSF implementation conditions and practices and is intended for internal use only. This document is based on MSF's experience and current knowledge which makes it provisional, not necessarily applicable to all contexts nor useful for all users, and subject to regular revisions and changes, if not removal altogether. MSF Operational Centre Brussels does not accept any responsibility or liability with regard to the use of information contained in this document by any third party.

Oxygen Humification

SOP – Please refer to the full procedure for rational and additional information on each step

Oxygen Humidification

SOP – Please refer to the full procedure for rational and additional information on each step

Humidification for oxygen therapy

No humidification is needed for standard oxygen flow rates. Humidification is only needed if the patient will be receiving **high flow rates for more than 2 hours**. High flow rates are >1L/min in neonates, >2 L/min in children under 2 years old, > 4 L/min in children over 2 years old and >6L/min in patients over 12 years old.

	Pre-procedure
	1. Perform hand hygiene
	2. Confirm the patient's identity
	3. Explain to the patient what is humidification therapy and why they need it
	4. Perform hand hygiene
	5. Clean/disinfect tray/trolley and pulse oximeter (with probe) and allow to dry
1	6. Verify that an oxygen therapy prescription has been written with oxygen saturation targets and that the oxygen therapy is suitable for the patient
	However, in emergency clinical situations, the healthcare provider can and should commence oxygen therapy without a prescription.
	7. Gather equipment on dry tray/trolley:
	a. Oxygen concentrator
	b. Water humidification chamber
	c. Medical distilled water
	d. Antibacterial filter kit (if needed) e. Pulse oximeter with appropriate probe
	f. Alcohol-based hand rub
	Procedure
	8. Set- up humidification system
	9. Turn on oxygen concentrator
	10. Perform hand hygiene
	11. If suctioning required, put on non-sterile gloves and perform suctioning
	12. Apply oxygen to the patient
	13. Monitor the patient's oxygen saturation with pulse oximeter and re-assess clinical signs
	14. Check that the patient is comfortable and allow patient the opportunity to ask questions regarding treatment
	Post-procedure
	Post-procedure 15. Clean/disinfect tray/trolley and pulse oximeter and probe
	15. Clean/disinfect tray/trolley and pulse oximeter and probe 16. Perform hand hygiene. If suctioning performed, remove non-sterile gloves, discard and perform hand